


Model 5401 Front-Panel Menu Structure



Screen Saver (each screen active for approximately four seconds)

